

Canopy fly screens

Each canopy fly screen kit contains the following items;

4 extrusions for the width and height

Screws or rivets

4 angled corner pieces

1 or 2 fly screen panels depending on the width of the canopy



Attach the angled corner pieces to the canopy with either self tapping screws or rivets

Canopy fly screens



Attach the angled corner pieces to the canopy with either self tapping screws or rivets



Build the canopy by joining and securing the 4 sections to the angled corner pieces. You will need to use a little force to insert the sections together.

Canopy fly screens



Once the canopy is assembled it can be fitted to your structure by drilling through the rear flange and then screwing it into position, ensuring that that you keep the canopy square.

When the canopy is in place fit the fly screen panels onto the outer flange by either screwing directly through the frame or using the hinges and turn buttons and self tapping screws supplied.