



# Fly Screen Door Installation Instructions

Each assembled door will come with the following components



Panel door/s

1 sub frame manufactured to your dimensions



3 hinges per door



Door handle



Brush strip



Assorted screws



1. Assemble the aluminium subframe ensuring that the brush pile is facing to the inner of the frame
2. Fix the subframe into position on the opening making sure that it is level all around by using the fixing lips
3. Screw the double action hinges into position on the panel door. Normally top and bottom hinges are around 20mm in and the 3<sup>rd</sup> hinge a third of the way down from the top of the door panel. But this will depend on your individual fitting circumstances.
4. Offer up the door into the subframe and once you are happy that it is level screw the top and bottom hinges into the subframe and then once you are happy with the operation secure the 3<sup>rd</sup> hinge in position.
5. Fit the brush pile and handle to the door. Make sure that the brush pile is just touching the floor otherwise it may impede the closing of the doors.





Secure the subframe to the opening / frame ensuring that it is dead straight



Fit the brush strips to the base of the door to seal the gap ensuring that the doors can still swing freely