



How to Measure for Double Action Fly Screen Doors

The dimensions ordered will be the overall size of the subframe which includes the fixing flanges.



Measure the overall height and width that you require the subframe to be remembering to allow for the fixing flanges that run around the perimeter, top and sides. This will be your ordering dimension, the subframe will be made to this measurement and doors will be manufactured to fit inside the sub frame.

