



Magnetic fly screen assembly instructions

Each fly screen kit contains the following items



4 corner pieces



Mesh insertion tool



4 magnets with screws



4 sections of Aluminium framing depending on screen size



Rubber beading



Fly mesh for 1 screen



Magnetic fly screen assembly instructions



1. The frame will be delivered pre cut to your exact dimensions so no need to reach for the saw.



2. Assemble the frame by pushing the corner pieces into the frame. You may need to use a hammer at this stage.



3. Lay the assembled frame on a flat surface with the inner groove facing you. Place the mesh over the panel and start to push the rubber gasket into the groove using the tool supplied. Trim off any excess mesh with a sharp Stanley knife.



4. You will then have the finished panel

5. Place the panel over the window opening in the desired position and mark the position of the corners with a pencil.

Remove the screen and the screw the magnets x 4 into the positions marked, corresponding with the corners. It is best not to over tighten the screws and to allow the magnets slight movement. Place the panel over the window and it will snap onto the magnets holding it in position.